

TLS-350 Series Sensor Modules

Installation Guide



Notice

Veeder-Root makes no warranty of any kind with regard to this publication, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

Veeder-Root shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this publication.

Veeder-Root reserves the right to change system options or features, or the information contained in this publication.

This publication contains proprietary information which is protected by copyright. All rights reserved. No part of this publication may be photocopied, reproduced, or translated to another language without the prior written consent of Veeder-Root.

DAMAGE CLAIMS

1. Thoroughly examine all components and units as soon as they are received. If damaged, write a complete and detailed description of the damage on the face of the freight bill. The carrier's agent *must* verify the inspection and sign the description.
2. Immediately notify the delivering carrier of damage or loss. This notification may be given either in person or by telephone. Written confirmation must be mailed within 48 hours. Railroads and motor carriers are reluctant to make adjustments for damaged merchandise unless inspected and reported promptly.
3. Risk of loss, or damage to merchandise remains with the buyer. It is the buyer's responsibility to file a claim with the carrier involved.

RETURN SHIPPING

For the parts return procedure, please follow the appropriate instructions in the "General Returned Goods Policy" and "Parts Return" pages in the "Policies and Literature" section of the Veeder-Root **North American Environmental Products** price list.

Introduction

Contractor Certification Requirements	1
Related Manuals	1
Safety Precautions	2
Warnings and Important Notes	2

Installation

Module/Connector Positions	3
Installing Modules	3
Connecting Sensor Wiring to Modules	5

Figures

Figure 1.	CPU/ECPU Boards - Battery Backup Switch in On Position	4
Figure 2.	Locating the intrinsically safe bay in the TLS Console	5
Figure 3.	Type A Interface Module Wiring Diagram	6
Figure 4.	Interstitial Sensor Interface Module Wiring Diagram	7
Figure 5.	Type B Interface Module Wiring Diagram	7
Figure 6.	Vapor Sensor Interface Module Wiring Diagram	8
Figure 7.	Groundwater Sensor Interface Module Wiring Diagram	8

Introduction

This manual contains procedures for the installation or replacement of the following sensor interface modules:

- Veeder-Root Type A Interface Module
Part No. 329956-001 (with console)
- Veeder-Root Type B Interface Module
Part No. 329950-001 (with console)
- Veeder-Root Vapor Sensor Interface Module
Part No. 329357-001 (with console)
- Veeder-Root Groundwater Sensor Interface Module
Part No. 329399-001 (with console)
- Veeder-Root Interstitial Sensor Interface Module
Part No. 329358-001 (with console)

The above parts are for TLS 350 Series Consoles designed and manufactured by Veeder-Root. This manual assumes all preliminary site preparation is completed, and that field wiring from the sensor junction box to the console is in place.

Contractor Certification Requirements

Veeder-Root requires the following minimum training certifications for contractors who will install and setup the equipment discussed in this manual:

Level 1 Contractors holding valid Level 1 Certification are approved to perform wiring and conduit routing, equipment mounting, probe and sensor installation, tank and line preparation, and line leak detector installation.

Level 2/3 Contractors holding valid Level 2 or 3 Certifications are approved to perform installation checkout, startup, programming and operations training, troubleshooting and servicing for all Veeder-Root Tank Monitoring Systems, including Line Leak Detection and associated accessories.

Warranty Registrations may only be submitted by selected distributors.







Related Manuals

If site preparation or field wiring is necessary, you must refer to the following manual for installation instructions:


576013-879 TLS-3XX Series Consoles Site Prep and Installation Manual






Safety Precautions

The following safety symbols may be used in this manual to alert you to important safety hazards and precautions

 EXPLOSIVE Fuels and their vapors are extremely explosive if ignited.	 FLAMMABLE Fuels and their vapors are extremely flammable.
 ELECTRICITY High voltage exists in, and is supplied to, the device. A potential shock hazard exists.	 TURN POWER OFF Live power to a device creates a potential shock hazard. Turn Off power to the device and associated accessories when servicing the unit.
 WARNING Heed the adjacent instructions to avoid equipment damage or personal injury.	 READ ALL RELATED MANUALS Knowledge of all related procedures before you begin work is important. Read and understand all manuals thoroughly. If you do not understand a procedure, ask someone who does.

Warnings and Important Notes

**WARNING**



You are working with a device in which potentially lethal voltages may be present.

This product is to be installed in systems operating near locations where highly combustible fuels or vapors may be present.

Fire or explosion resulting in serious injury or death could result if the equipment is improperly installed or modified. Serious contamination of the environment may also occur.

1. Read and follow all instructions in this manual, including all safety warnings.
2. Turn POWER OFF before installing these modules.
3. Comply with all applicable codes including: the National Electrical Code; federal, state, and local codes; and other applicable safety codes.
4. Substitution of components may impair intrinsic safety.
5. Do not use this component for other systems aside from the TLS Console. Install only as described in this manual.

Failure to install this product in accordance with its instructions and warnings will result in the voiding of all warranties connected with this product.

To help ensure proper installation and unit performance, we recommend that a Veeder-Root Authorized Service Contractor install this equipment.

Installation

Module/Connector Positions

Installing interface modules in a TLS-350 Series Console is a simple process. However, there are important points to remember:

1. For each module, a corresponding expansion slot with connector must be available.
2. ALL unused expansion slots **MUST** be covered with blank face plates.

MODULE POSITION

- Record in the circuit directory (inside front panel), the type of module, sensor locations, etc., beside the slot number.
- Once a particular type of module has been installed in that slot, the system will always look for that type of module in that slot.



CONNECTOR POSITION

- Identify all connectors according to their slot location using the self-adhesive numbering labels supplied with each module.
- Once a device has been wired to certain terminals on the connector and the system has been programmed, terminal positions may not be changed without reprogramming the system.

Installing Modules

The steps below apply for any of the sensor modules discussed in this manual. Additional information regarding the below steps can be found in the Veeder-Root TLS-3XX Series Consoles Site Preparation and Installation manual.

1. Open the right-hand door of the console by unscrewing the right-top and right-bottom locking bolts.
2. To retain current programming, be sure that the CPU (for TLS-350) or ECPU (for TLS-350R) battery backup switch is in the On position (see Figure 1 on page 4). If you have to set the battery backup switch to the On position, avoid touching any circuit components with your hand or any conductive tool.

 WARNING	
	<p>You are working with a device in which potentially lethal voltages may be present.</p> <p>If high voltage is shorted across any barrier terminal, explosion and fire could result.</p> <p>Turn Off, tag and lockout power to the console before installing/wiring any module.</p>




Figure 1. CPU/ECPU Boards - Battery Backup Switch in On Position



3. Locate the IS bay in the right side of the console (Figure 2). Avoid shorting high voltage across any component or module to the intrinsically safe (IS) bay of the console. This could result in an explosion near the sensor.




Figure 2. Locating the intrinsically safe bay in the TLS Console

4. Remove the blank panel from the desired module slot in the IS bay.
5. Carefully slide the new module into the slot until the connector on the rear of the module engages completely with the connector on the expansion board at the back of the slot. Do not apply excessive force.
6. Press in the snap-in fasteners on each side of the module's face plate to "lock" the module in place.
7. When finished installing modules, make sure all unused slots in the console are covered with snap-in blank plates! (Veeder-Root Module Cover Part No. 329339-001.)



IMPORTANT! If you are installing these modules in a system that has already been programmed, you cannot change the position of existing modules and/or connectors without reprogramming the entire system. If any connectors were removed during installation, be sure they are reconnected to their original modules. Improper system operation will result if any sensor/module position is changed without re-programming.

Connecting Sensor Wiring to Modules

Connectors are supplied with each interface module. They provide screw terminations for sensors. See Table 1 on page 6 for interface module type and its maximum allowed number of sensors. Be sure to record on the circuit directory the type of module and the name or location of each sensor wired to each connector.

Table 1.- Maximum Sensors Per Interface Module

Interface Module	Number of Sensors
Type A	8
Type B	6
Vapor Sensor	5
Groundwater Sensor	5
Interstitial Sensor	8

TYPE A AND INTERSTITIAL SENSOR MODULES

For Type A and Interstitial Sensor Interface Modules, connect the two marked or color-coded wires from each sensor to the appropriate terminals (see Figure 3 and Figure 4). Be sure to maintain the proper polarity between the sensor wires and their respective module connector terminals.




Figure 3. Type A Interface Module Wiring Diagram




Figure 4. Interstitial Sensor Interface Module Wiring Diagram

TYPE B, VAPOR SENSOR, & GROUNDWATER SENSOR MODULES

For Type B, Vapor Sensor, and Groundwater Sensor Interface Modules, connect the three marked or color-coded wires from each sensor to the appropriate terminals (see Figure 5, Figure 6, and Figure 7 on page 8):




Figure 5. Type B Interface Module Wiring Diagram




Figure 6. Vapor Sensor Interface Module Wiring Diagram




Figure 7. Groundwater Sensor Interface Module Wiring Diagram

Veeder-Root has sales offices around the world to serve you.

Headquarters

125 Powder Forest Drive
Simsbury, CT 06070-7684
Tel: (860) 651-2700
Fax: (860) 651-2719
Email: marketing@veeder.com

Australia

21 Highgate Street
Auburn 2144
NSW Australia
Tel: +61 2 8737 7777
Email: rxdupuy@veeder-australia.com

Brazil

Rua ado Benatti, 92
Sao Paulo - SP 05037-904
Tel: +55 (0) 11 3611 2155
Fax: +55 (0) 11 3611 1982
Email: clopez@veeder.com

Canada

Eastern Canada
Tel: (519) 925-9899
Western Canada
Tel: (604) 576-4469
Email: marketing@veeder.com

China

Room 2202, Scitech Tower
No. 22 Jian Guomen
Wai DaJie
Beijing 100004
Tel: +86 10 6512 8081
Fax: +86 10 6522 0887
Email: lu ying@veeder.com

England

Hydrex House, Garden Road
Richmond, Surrey TW9 4NR
Tel: +44 (0) 20 8392 1355
Fax: +44 (0) 20 8878 6642
Email: sales@veeder.co.uk

France

94-106 Rue Blaise Pascal
93600 Aulnay Sous Bois
Tel: +33 (0) 1 4879 5599
Fax: +33 (0) 1 4868 3900
Email: sales@veeder.co.uk

Germany

Uhlandstrabe 49
78554 Aldingen
Tel: +49 (0) 7424 1400
Fax: +49 (0) 7424 1410
Email: sales@veeder.co.uk

Mexico

Sagitario #4529-3
Col. La Calma C.P. 45070
Zapopan, Jalisco
Tel: (523) 632 3482
Fax: (523) 133 3219
Email: jmartinez@veeder.com

Poland

01-517 Warszawa ul. Mickiewicza 18/12
Tel/Fax: +48 (0) 22 839 08 47
Email: sales@veeder.co.uk

Singapore

246 MacPherson Road
#08-01 Betime Building
348578
Tel: +65 (0) 6745 9265
Fax: +65 (0) 6745 1791
Email: francis yap@veeder.com

